



IMPORTANT: Please read the ENTIRE instructions before beginning. This Curb Mount Step Flashing Kit **MUST** be installed with the Kennedy Curb Mount Skylight in order to qualify for the Lifetime Leakproof Warranty. Failure to follow the instructions will void the Warranty.

LIMITED
LIFETIME
WARRANTY
TRADITIONAL SKYLIGHTS

INSTALLATION SHOULD ONLY BE COMPLETED BY INDIVIDUALS SKILLED WITH THE NECESSARY TOOLS FOR INSTALLATION. IF YOU DOUBT YOUR SKILLS, PLEASE CONSULT A QUALIFIED INSTALLER.

Kennedy Step Flashing Kit Components:



- A.** (1) Head Flashing 5" x 10" x 35"
- B.** (2) Head Step Flashing Corner 5" x 6" x 9"
- C.** (18) Step Flashings 5" x 6" x 9" (number needed will vary on skylight size)
- D.** (2) Sill Step Flashing Corners 5" x 6" x 9"
- E.** (1) Sill Flashing 5" x 6" x 35"
- F.** (8) Counter Flashings 1" x 3 1/2" x 23"
- F.** (1) Installation Tape 9" x 18 3/4 feet

Materials and Tools Needed:

- Kennedy Curb Mount Skylight
- Pre-Built Curb - 2" x 6" recommended
- Adhesive Roof Membrane
- Caulking Gun
- Common Nails
- Drill
- Hammer
- Roofing Nails
- Safety Glasses
- Sealant
- Tin Snips


USING A 2" x 4" CURB?

If using a 2" x 4" curb, **ALL** flashing pieces **MUST** be cut down to a height of 3 3/4" using tin snips. Use caution when handling sharp edges of cut pieces.




NOTE: This Curb Mount Step Flashing installation instructions should be used along with the installations instructions that came with your Kennedy Curb Mount Skylight. Please refer to those instructions for additional installation steps.

CAUTION: Do NOT use step flashing on tar and gravel roof installations.




STEP ONE - INSTALL CURB

Accurately line up the pre-built curb with the rough opening and nail securely to roof deck. Kennedy Skylights recommends using a 2" x 6" curb. Caulk all seams around the curb liberally with sealant.




STEP TWO - INSTALL INSTALLATION TAPE

Cut (2) pieces of installation tape (**F**) 12" longer than the width of the curb and (2) pieces 12" longer than the length of the curb. Starting at the front (sill), wrap the curb and roof deck with installation tape to extend 6" on each side. Wrap the left side, right side and back (head) areas with the installation tape.




STEP THREE - INSTALL SILL FLASHING

Replace first row of shingles before the curb. Place the sill flashing (E) so it rests on top of shingles. Nail the sill flashing to the curb. Do not nail sill flashing lip to shingles.




STEP FOUR - INSTALL SILL STEP FLASHING CORNER

Line up the top edge of the sill step flashing corner (D) with the edge of the curb so that the angle points down the roof slope. Secure with nails to the curb or roof deck. Replace shingles but do NOT nail through sill flashing.




STEP FIVE - INSTALL STEP FLASHING

Install the step flashing pieces (C) on both sides of the curb using a **minimum overlap of 2 1/2"**. Work your way to the top interweaving each step flashing with a roof shingle. Leave room at the very top for the head step flashing corner installed in Step Six.




STEP SIX - INSTALL HEAD STEP FLASHING CORNER

Place head step flashing corners (B) over the curb corners and nail to curb or roof deck. Replace shingles over head flashing corners but do NOT nail through flashing.




STEP SEVEN - INSTALL HEAD FLASHING

Place head flashing (A) at the top of the curb so that it sits OVER the lip of the head flashing corner (B). Nail to curb or roof deck. Replace shingles over head flashing but do NOT nail through head flashing.




STEP EIGHT - SEAL SEAMS

Caulk all seams, joints and exposed nail heads with sealant, especially at all four corners.



STEP NINE - INSTALL COUNTER FLASHING

Nail the counter flashing (F) over entire curb outside perimeter. Begin with the front sill. Then, work your way each side of the curb overlapping each counter flashing a minimum of 2 1/2" and finish with the head counter sill.



STEP TEN - INSTALL KENNEDY SKYLIGHT

Carefully place the Kennedy Curb Mount Skylight over curb. Using the provided self-tapping screws with washers, attach to the curb through the pre-punched holes on the side of the skylight.